

SIMPLE HOW TO'S FOR DSC KEYPADS

Change Date/Time	Press * (star symbol) then press 6 Enter your 4-digit alarm code Press number 1 Then enter time in 24 hour format (HH:MM) example 14:30 Next enter the date in (MM:DD:YY) format example 02/20/13 Finally press # (number symbol) when done
Reset	Press # (number symbol)
Arm (See note below)	Enter your code (do not need to enter code w/h some models) Press word (AWAY) or might be a symbol (house) Press word (STAY) or might be a symbol (house w/h person inside)
Disarm	Enter your code
Bypass	Press * (star symbol) Then press the number 1 Then enter the 2 digit zone # e.g. 03
Silence Fire	Press # (number symbol) Reset Smoke * (star symbol) Then press the number 7
Silence Beeping	Press # (number symbol)
Chime On/Off	Press Chime Key or * (star symbol) Then press the number 4
Trouble Misc	Press * (star symbol) Then press the number 2 The Zone number where the trouble is will appear This could be as simple as a window is slightly open?
Check A/C Loss	Press * (star symbol) Then press the number 2 If there is A/C Loss the number 2 will appear Note: Call office for assistance
Check Low Battery	Press * (star symbol) Then press the number 2 If there is a low battery the number 1 will appear Note: Call office for assistance
Check Communication Failure	Press * (star symbol) Then press the number 2 If there is a communication failure either number 3 or 4 will appear Note: Call office for assistance

Please note: User Manuals can also be downloaded from this website

Zone numbers should be written on your keypad door. If they are not, or have become illegible please call the office and we will be happy to assist you.